

Import the proper Iso-curves into your CAD drawing
IES Photometric files WPLK3 AC Mode S1811083-R1
Iso curves in footcandles
unit: feet

