

Import the proper Iso-curves into your CAD drawing  
IES Photometric files PHR03-A1-3W90  
Iso curves in footcandles  
Unit: Feet

